



[Carbon Fiber Engine Cover, 8V Audi S3 & MkIII Audi TTS](#)



Supplied Parts:

- 034Motorsport Carbon Fiber Engine Cover
- Pre-Applied 3M Adhesive Strips
- Scene Points

Tools Needed:

- Hands (2) (*Opposable thumbs are required!*)
- Isopropyl Alcohol
- Towel
- Patience

034Motorsport's Carbon Fiber Engine Cover for the 8V Audi S3 & 8S Audi TTS is designed to tastefully complement the factory engine bay with a beautiful carbon fiber weave that is perfectly matched to our X34 Carbon Fiber Audi S3/TTS Air Intake.

This genuine carbon fiber cover is an overlay for the plastic factory engine cover, retaining the factory Audi rings and TFSI logo for a true OEM+ appearance.

Installation of this upgrade is a simple process that takes approximately 30 minutes from start to finish.

Step 1 – Using the process detailed in the Genuine Audi/Volkswagen Owner's Guide for your vehicle, open the hood to access the engine bay.

Step 2 – Open the box for the 034Motorsport Carbon Fiber Engine Cover. Look at how pretty it is.

Step 3 – Locate the factory Engine Cover. **Hint:** It's really hard to miss.



Step 4 – Using a towel and isopropyl alcohol, thoroughly clean the factory Engine Cover.



Step 5 – Peel the backing off of the 3M Adhesive Strips on the Carbon Fiber Engine Cover, exposing the adhesive.



Step 6 – Carefully begin setting the Carbon Fiber Engine Cover over the factory plastic part.



Step 7 – Once the Carbon Fiber Engine Cover is properly aligned, press down firmly to ensure the adhesive strips stick to the plastic cover beneath it.



Step 8 – Marvel at your work!

